

Exploded View

MHP Starting Motor

No.	Description	Part No.	MHP-4004	MHP-4101
1	Armature	MHJ-3151S	•	
		MHJ-2147S		•
2	Brush Set	MDL-2012ES	•	•
3	Frame & Field Assy.	MHP-3039AS	•	
		MHP-2101S		•
4	Comm. End Head Assy.	MDL-1002	•	
		MDT-1002		•
5	Drive End Head Assy.	MCL-1137	•	
		MHP-2003		•
6	Bearing & Seal Package	90-2118	•	
		ML-18A		•
7	Brush Plate Assy.	MDL-1064ES	•	
		MDL-1065E		•
8	Brush Spring Set	MZ-19S	•	•
9	Term. Stud Package	90-726	•	
		90-711		•
10	Thru Bolt Package	MAJ-20CS	•	
		GJ-20DS		•
11	Thrust Washer Package	90-2232	•	
		90-2677		•
12	Spacing Ring Assy.	MHP-1002		•
13	Oil Seal	90-2118	•	
		XA-1024		•

